

‘MACAW’ Pipe Cracker


Parts List




LARGE 'MACAW' PIPE CRACKER

For safe, effective breaking out of redundant, or inserted cast iron mains.

Available for hire or purchase.




Description	Part No.	
MACAW Base unit only	025101	
MACAW Pipe Cracker c/w 8" Beak	025101/8	
MACAW Pipe Cracker c/w 9/10" Beak	025101/910	
MACAW Pipe Cracker c/w 12" Beak	025101/12	
MACAW Pipe Cracker c/w 14" Beak	025101/14	
MACAW Pipe Cracker c/w 15" Beak	025101/15	
MACAW Pipe Cracker c/w 16" Beak	025101/16	
MACAW Pipe Cracker c/w 18" Beak	025101/18	
MACAW Pipe Cracker c/w 20" Beak	025101/20	
MACAW Pipe Cracker c/w 24" Beak	025101/24	


Additional Beak available		
Description	Part No.	
8" Beak	025102	
9" and 10" Beak	0251025	
12" Beak	025103	
14" Beak	025104	
15" Beak	025105	
16" Beak	0251055	
18" Beak	025106	
20" Beak	025107	
24" Beak	025108	
High Powered Arm For class C and D CI pipe	038005	
Pressure Gauge	025110	
Pressure gauge adapter 3/8" x 1/4"	025109	

HD MINI 'MACAW' PIPE CRACKER


Description	Part No.	
HD Mini MACAW Pipe Cracker, c/w chain 4 – 8" Without box	039122/HD	
HD Mini MACAW Pipe Cracker, c/w chain 4 – 8" With box	039122/HDT	

Spares and Accessories for HD Mini Macaw Arms		
Description	Part No.	
Link Arms – Lower (inner & outer)	039028HD	
Link Arms – Upper (inner & outer)	039115/HD	
Link arm spacer	039031/HD	
Cutting Wheel	039032/HD	
Hydraulic Ram	039200HD	
Yoke	039025HD	
Ram Pin – Top	039020/HD	
Ramp Pin – bottom	039023HD	

Spares and Accessories for Mini Macaw Arms		
Description	Part No.	
Lower Arm Set – Inner	039028	
Lower Arm Set – Outer	039027	
Inner Link Arms 117mm outside to outside	039115	
Inner Link Arms 139mm outside to outside	039019	
Hydraulic Ram	039200	
Yoke	039025	


Description	Part No.	
Yoke Pin	039023	
Bush	039024	

Machine Spares and Accessories		
Description	Part No.	
Pin – 19mm Link arms and yoke to jaws	039022	
Pin – 25mm Long Top Ram Pin and for Outer jaws to wheels	039020	
Pin – 25mm Short For inner arms to wheel	039021	
Wheel Spacer	039029	
Cracking Wheel	039026	

Universal Spares and Accessories		
Description	Part No.	
Spacer – 3 – 6"	039012	
Sling Bracket with chain	038111	
Sling Bracket Pin – 30mm	022108	
Sling Bracket Pin – 25mm	022109	
Van Vault Storage Box	039018	
Point Load Spike	039040HD	
Quick link chain	038113	

Description	Part No.	
Coupling – 3/8”, flat face -Male	142032	
Coupling – 3/8”, flat face-Female	142033	
Flow control valve	022115	

HIRE

Description	Part No.	
MACAW Pipe Cracker 8 -24" You need to state "beak" size required when hiring, depending on the pipe you wish to crack. Comes with 1 beak		
Additional Beaks -		
8"		
10"		
12"		
14"		
15"		
16"		
18"		
20"		
24"		
HD Mini MACAW Pipe Cracker 4" – 8"		

Minimum 5 Days Hire Period

Pipe Handling Equipment

- Pipe Coil Trailer 50 - 90
- Pipe Coil Trailer 125 - 160
- Pipe Coil Trailer 180
- Pipe Coil Trailer Hexi
- Pipe Handler 125 Mini (for use with a 1.5-ton digger)
- Pipe Handler 180 Midi (for use with a 3-ton digger)
- Pipe Handler 355, 500, 630, 900 (for use with 5-8 tonne, may suit larger size diggers)
- Perpetual Pipe Pusher 63 – 180mm Pipe
- **NEW** - Coil Control Unit
- **NEW** – Long Reach Band Cutter (LRBC)



Pipe Cutting/Cracking Equipment

- Hire Parts & Price List (plant hire)
- Keel Cutter (N450 & N600 require power pack for use, also available)
- MACAW Pipe Crackers – Mini MACAW 3 – 8" and MACAW – 8 – 24"
- Rapid Pipe Cutters – Window and Circumferential cutters for Ductile
- Steel Pipe Cutters – Window and Circumferential cutter for Steel
- Crackerjack™
- PE Pipe Cutter

Gas Service Renewal

- Dead Service Insertion 17.5mm (17.5 sealant cartridges)
- Live and Dead Service Insertion (rigid 4-wheel cutter, FOAMPACK™, nosecones, mini end seals, taper tools)
- Live Service Insertion -20-25mm (Pushing machine for use with the kit, FOAMPACK™, nosecones, mini end seals)
- Live Service Insertion 32mm (Pushing machine for use with the kit, FOAMPACK™, nosecones, mini end seals)
- Live Service Isolator - Generic Large (Isolators with clamps, etc.)
- Live Service Isolator - Generic Small (Isolators with clamps, etc.)
- Live Service Transfer (Drills, hole saws, foam stop tees, and kits)
- Rapid Service Isolator (Applicator gun, kit bag, and sealant)
- Service Removal Tool (Service removal tool, 4-wheel cutters)

Live Mains Insertion

- Live Mains Insertion (Lyontec Gland boxes, Insertion and End Seals, Live Heads and Test Ends)

Flowstopping/Pipe Sealing

- Flow stop & Abandonment (FOAMBAG™, Dead End Seals, Foam Caps, Hacksaw Blades)
- Mini Purge Ejector
- DRAINBLOCK BAG™ and RATBLOCK™



01225 864 864 | info@stevevick.com | stevevick.com

Registered office: Steve Vick International Ltd, Treenwood Industrial Estate, Bradford-on-Avon, Wiltshire, BA15 2AU. Registration No. 1564477

Steve Vick International reserve the right to amend specifications without prior notice. © Steve Vick International Ltd 2021. All Rights Reserved